

Installing an Original Suzuki PTO Kit on an LJ10

Bill Hutchison

502-899-3154

wchutc01@gwise.louisville.edu





Front CV joint with cover in place



The pix on the right show the brackets for the mounting rails. (Top) The long one is to be welded on top of the frame and the two smaller ones are then welded on to the long one. (Bottom) The little bkt on the rear frame member also has to be welded into place.

